

### **User Manual**


123inkt Power Strip Tower with 8 Outlets and 4 USB Ports, Black (2 Meters)

Product Code: 390026

123inkt Power Strip Tower with 12 Outlets and

5 USB Ports, Black (2 Meters)

Product Code: 390027




#### Introduction

Thank you for choosing the 123inkt Power Strip Tower with (8 or 12) Outlets and (4 or 5) USB Ports, Black (2 Meters). This product is designed for safe and efficient charging and powering of multiple devices. Please read this manual carefully before use to ensure proper operation and avoid potential hazards.


#### **▲** Important Notice

This product must be used in accordance with the instructions provided in this manual. Improper use, including exceeding the power or current limits, may result in safety hazards such as fire, electric shock, or damage to connected devices.

By using this product, the user accepts full responsibility for its operation and assumes all associated risks. The manufacturer and distributor are not liable for any damage, injury, or loss resulting from misuse, negligence, or failure to follow the safety guidelines outlined in this manual.



- 1 AC Outlets
- 2 USB-A Charging Ports
- 3 LED Power Indicator
- 4 ON/OFF Switch
- 5 USB-C Charging Ports
- 6 Overload Protector



# **Usage Instructions**

### 1. Connecting Devices

Plug the power strip into a standard AC wall outlet. Make sure the ON/OFF switch is in the "ON" position.

### 2. Using USB Ports

Connect your USB devices to the available USB-A or USB-C ports. Do not exceed the total output rating of the USB ports.

# **Specifications**

Model	390026	390027
Interface	8 Outlets + 2 USB-A Ports + 2 USB-C Ports	12 Outlets + 3 USB-A Ports + 2 USB-C Ports
Current	16A	
Voltage	220-250V~	
Power	4000W MAX	
Frequency	50/60Hz	
Cable	H05VV-F 3G 1,5mm <sup>2</sup>	
USB-A Output	5V==2,4A (Totaal)	
USB-C1 Output	20W (5V=3A, 9V=2,22A, 12V=1,67A)	
USB-C2 Output	5V==2,4A	
Dimension	150 x 136 x 170mm	150 x 136 x 230mm

## **Important Warnings**

- Ensure that the power plugs or power cables of your devices are fully inserted into the power strip outlets to prevent electric shock.
- Do not use the power strip with wet hands or in wet locations.
- Do not disassemble the power strip yourself. For technical support, contact the vendor or hire a qualified electrician.
- Keep the power strip away from heat-emitting appliances, flammable materials, and explosive substances.

# Warnings

To ensure safe and proper use, follow these warnings:

#### 1. Electrical Safety

- Always check the voltage and current ratings of the power strip and connected devices before use.
- Avoid overloading the power strip. The total power should not exceed 4000W.
- Disconnect the power strip during thunderstorms or if not in use for an extended period.

#### 2.Placement Safety

- Place the power strip on a flat, stable surface to prevent tipping.
- Keep the power strip away from water, humidity, and other liquids to avoid electrical hazards.

#### 3. Fire Prevention

- Do not place the power strip near heat-emitting appliances such as radiators or ovens.
- Keep flammable materials (e.g., curtains, paper, chemicals) away from the power strip.

#### 4. Child Safety

- Keep the power strip out of reach of children.
- Use safety covers for unused outlets if necessary.

#### 5.Cable Management

- Do not bind or wrap the cables too tightly to prevent overheating.
  - Regularly inspect the cable for wear and tear, and replace it if necessary.

### **Troubleshooting**

### 1. When to Reset

If the power strip shuts down due to overload:

- · Disconnect all connected devices.
- Press the reset button located at the bottom of the power strip.
- Reconnect the devices, ensuring the total load does not exceed 4000W.

#### 2. Why USB Ports are Not Working

Possible reason ①:

The power strip is not fully plugged into the wall outlet.

• Solution: Ensure the power strip is securely plugged in.

#### Possible reason 2:

The ON/OFF switch for the USB charging ports is turned off.

• Solution: Make sure the USB switch is turned on.

#### Possible reason ③:

The total current of attached devices exceeds the USB output limit.

• Solution: Disconnect some devices to reduce the load.



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment.











Made in China